

HKS ELECTRONICS TECHNOLOGY

F-CON ***NAVIGATOR*** ***FUEL & IGNITION TIMING COMPUTER***

Instructions Manual

This manual assumes that you have and know how to use the tools and equipment necessary to safely perform service operations on your vehicle. This manual assumes that you are familiar with typical automotive systems and basic service and repair procedures. Do not attempt to carry out the operations displayed in this manual unless these assumptions are correct. Always have access to a factory repair manual. To avoid injury, follow the safety precautions contained in the factory repair manual.



Preface

We HKS CO., LTD will like to thank you for purchasing the HKS F-CON Navigator.

Please read this manual before installing the product for safe operations & optimal use.

Name of the product:	F-CON Navigator
Use of the product:	This product is the optional item for F-CON S, F-CON SZ, and F-CON V Pro (Ver.3 or newer) to confirm the input/output signals from them This product is allows you to edit and adjust the data in F-CON S and F-CON SZ.
Applicable Vehicle Model:	Vehicle with F-CON S, F-CON SZ, or F-CON V Pro installed.
Code Number:	42999-AK003
Note:	

F-CON Navigator shows the following values of sensors from F-CON S, F-CON SZ, and F-CON V Pro on its monitor.

- Engine RPM
- Airflow Input voltage (frequency)
- Cooled water temperature & intake air temperature
- Injector duty
- Ignition timing

Values displayed on the monitor are varied due to the type of F-CON connected with F-CON Navigator.

The F-CON Navigator can edit the setting data.

Individual settings can be made due to each engine spec which includes upgrades like the type of intake or exhaust installed on the vehicle.

The data on F-CON V Pro cannot be edited.

The F-CON Navigator emits a warning sound when your vehicle goes beyond the set value of the engine rpm and/or the airflow voltage.

The instructions manual is for safe use of this product and to prevent any trouble. When you would like any lost parts or consumption parts, contact the store you bought the product.

The product name, part number, and engine type of your vehicle are needed to find correct parts you look for.

See the parts list for the part numbers.

No warranty for any damage caused by misuse by the customer and/or the third party.

No warranty for the product quality if installed on to any vehicle not applicable.

Make sure the serial numbers on the product and the warranty papers match.

The specifications of the product are subject to change without notice.

The installation manuals are subject to revision without notice.

The customer must keep the guarantee and installation manuals.

This product is designed for use in Japan only.

It must not be used in any other countries.

INDEX

Preface.....	1
Index.....	2
Safety Instructions.....	2
Parts List	4
Name of Components	5
Installation	6
Operation.....	7
1. Initial Operation	8
2. Menu.....	8
3. Monitor	10
4. Edit.....	16
5. System.....	21
Maintenance.....	26

SAFETY INSTRUCTIONS

The following indicate the level of danger involved in operation.



Danger

There is a possibility for an operator or user to get seriously injured or killed.



Warning

There is a possibility for an operator or user to get seriously injured or killed.



Caution

There is a slight possibility for an operator or user to get seriously injured or killed.

Warning

Installation must be done in a well-ventilated place to prevent explosion or fire.

Do not attach the product anywhere that interferes with driving or cannot support the product properly.

Remove the minus terminal from a battery before installing to prevent a short circuit, which would cause a fire.

Hold connectors while taking them off to prevent disconnection.

When something unusual, such as offensive smell and/or strange noise, is occurred under the use of the product, stop the use immediately, and contact the store you bought the product or the customer service for advice.

Continued use may cause electric shock, fire, or damage on any components.

Do not operate the F-CON Navigator while driving to prevent a car accident.

Cautions

The product must be installed by experts; special knowledge, technique, and/or tool are required.

Wrong use would cause damage to the vehicle.

Never modify, overhaul, and/or reconstruct any parts in the product.

It would cause damage, a fire, and/or an electric shock.

Always handle the product with care.

Any kind of liquid must be avoided.

It would cause serious damage to the vehicle.

Make sure the temperature inside the engine room is less than about 40 degree Celsius before installation.

Avoid high temperature or watery place for installation to prevent a short circuit.

Wiring must be done with care.

◦ It's your responsibility to maintain your vehicle.

Please check the vehicle condition daily.




Put the stock parts aside for installation until you need them.

Use appropriate tools to tighten bolts and nuts.

Be careful for not disconnecting the wires from a vehicle when connecting the product.

PARTS LIST

The following are the parts included. Please check them for damage.

							
1	F-CON Navigator	2	Bracket 1 (base)	3	Bracket 2 (stand)	4	Bracket 3 (bolt)
	1		1		1		1
							
5	Bracket 4 (inner tooth washer)	6	Bracket 5 (washer)	7	Bracket 6 (nut)	8	Bracket 7 (double-side tape)
	2		2		1		1
							
9	6angle wrench	10	Installation manuals	11	Guarantee		
	1		1		1		

(example) part form


		part name
10	Installation manuals	
part No.	Code No.	quantity
		1

Please keep the parts not used.

The following is the required tools for installation.....Screw Driver・Socket Wrench


Name of components

F-CON Navigator



1. Display
It shows the engine information, the editing data, and the menu for setting.
2. Arrow button
Use the arrows to select an item from the menu or the data to use, and to increase or decrease the data value when editing.
3. Mode button
Use this button to move to the upper menu or cancel the item chosen.
4. Set button
Use this button to move to the lower menu or execute the action/item chosen.
5. Harness
It connects to the option port of F-CON S, F-CON SZ, and F-CON V pro.

Holder Assembly Drawing



INSTALLATION

This product is designed specifically for certain vehicle applications. Do not modify the harnesses or install them in any other way than specified. Doing so, may result in a fire. This manual explains the basic procedures. There are different ways of installation due to the type of vehicle.

1. Removing from the battery terminal

(1) Remove the negative (-) cable from the battery terminal.

2. Installing the main unit

(1) Decide the where to position the F-CON Navigator unit.

advice

- The length of the harness is 2 meters, so the distance between the main unit and harness must be within that range.
- Position the unit where it will not interfere with the driver's view.
- The unit is very sensitive to heat. Please place the unit away from heat and sunlight.


(2) Clean the surface of the place parts installed with mild detergent.

(3) Set up the bracket P2 - P8.


(4) Secure the bracket and the F-CON Navigator.

(5) Connect the harness from F-CON Navigator with the coupler on F-CON S, F-CON SZ, or F-CON V pro.

F-CON S, F-CON SZ



F-CON V Pro



- (6) Set the DIP switch referring to the manual
 - F-CON S or F-CON SZ: Set the DIP switch 8 to ON
 - F-CON V pro: Set the DIP switch 6 to OFF.

3. Reconnect the battery terminal.

- (1) Connect the negative (-) cable back onto to the battery terminal

Check the following after installation

1. Before the engine start check if

check item	check
the harness connected correctly.	
the harness was not disturbed by other items.	
the main unit or harness attached firmly.	
the battery terminal connected correctly.	
bolts or nuts were tightened firmly.	

2. After the engine started check if

check item	check
the engine idles at the normal engine RPM.	
the engine accelerates smoothly when stepping on the gas.	

OPERATION

Caution

Do not operate F-CON Navigator during driving.
 Editing data must be done by experts.
 The special tools for setting, knowledge, and/or technique, are required.

advice


- For F-CON SZ, save the data often. (See Sec. 5.5)
- For F-CON S, record the current data for review before changing any data.

1. Initial Operation

- (1) When the ignition is on, the demo screen appears on the monitor, and the buzzer sounds.
- (2) The top menu appears.

advice


You can select how the top menu appears. (See Sec. 5.4)



2. Menu

- The MODE button is used to cancel the selected item on the menu, and to move to the upward menu .
- The SET button is to execute the selected item on the menu, and to move to the downward menu.
- The item selected is highlighted. The highlighted item is called a CURSOR. There are some items on the menu cannot be selected or executed. Those items cannot be overwritten by the F-CON Navigator.

MENU STRUCTURE



3. MONITOR

3.1. Monitor Menu

3.1.1. Main menu

Monitor Menu consists of the following 4 items

- Bar
- Big
- Small-L
- Small-R

These 4 items show the following as the default setting.

- Bar: Engine rpm
- Big: Airflow meter voltage
- Small-L: Water temperature
- Small-R: Power voltage


Press the MODE button to return to the top menu.

Press the SET button to go to the monitor setup menu.

advice

The items will not display a correct value if the option sensors are not connected.

If so, install the option sensors or select other items to monitor.



3.1.2. Peak Hold Display

Press the up or down arrow button () to switch to peak hold display.

The peak hold display shows the maximum value of 'Bar', 'Big', and 'Small-L' and the minimum value of 'Small-R.'

These values are called the 'peak hold value.'

Press the right arrow button () to reset the peak hold value, and use the up and down buttons to go back to the main screen.

3.1.3. Warning Display

When the actual value is over the value entered at the warning setup (See Sec. 5.1), the F-CON Navigator gives you warning.

The F-CON Navigator alarms you by an audible sound and <W-item> will be highlighted. When the warning stops, <W-item> start blinking.

Warning items

- “ B ” mark : Boost conditions
- “ A ” mark : Airflow conditions
- “ K ” mark : knock conditions
- “ I ” mark : Injout conditions

To stop the blinking, reset the warning value in the diagnosis check/delete menu (See Sec. 5.3).

3.1.4. Scramble Setup

In the main menu, press the left arrow button () to activate scramble correction.

When the scramble correction is activated, the 「SCR」 display appears as below:

advice


However, the default setting of the scramble setup is not set to any value. The correction cannot be activated by pressing any button.

3.2. Monitor Setup Menu

The default setting of the items, Bar, Big, Small-L, and Small-R, on the monitor menu can be changed.

Press arrow buttons () to select one, then press the SET button.

Press MODE button to return to the main menu.



3.2.1. 'BAR' Display Setup


Select one of the following 6 items for 'BAR'

- Rev • Airflow • Speed • Boost • Knock • Inj.out

Press arrow buttons () to select one, then press the SET button.

An asterisk (*) appears on both sides of the item selected.

Press the MODE button to return to the main menu.



Rev. : Engine rpm (r/m).

Boost : Engine intake air pressure (×100kpa).

* The unit measurement can be changed (see Sec. 5.6.5).

Note:

The boost value of the F-CON NAVIGATOR is absolute pressure value. This value is determined by the vacuum condition. Generally, the boost value of a boost meter or boost controller is relative pressure value, which is determined by the atmospheric pressure. Therefore, the boost value of F-CON NAVIGATOR is not the same value of the boost meter or controller.

The standard atmospheric pressure value is 760mmHg, and the bottom line of the conversion table shows its converted values. These values may differ slightly from the actual value due to the difference in environment. However, to show the psi value, the value set at the standard atmospheric pressure (14.6960psi) is offset to 0. When showing the psi value and if its value is less than the standard atmospheric pressure, the value will be underlined.

The absolute pressure value (0 at the vacuum state.) shows as the pressure value. Please refer to the unit conversion table.

Unit conversion Table:

Unit	×100kPa	bar	kg/cm ²	psi	mmHg
	1	1	1.01972	14.5037	750.062
	0.980665	0.980665	1	14.2233	735.559
	0.0689476	0.0689476	0.070307	1	51.7151
	0.00133322	0.00133322	0.00135951	0.0193367	1
standard atmospheric pressure value	1.01325	1.01325	1.03323	14.6960	760

AirFlow : Input airflow value (mV/Hz).

The F-CON Navigator will display the input signal values for F-CON S and F-CON SZ.

(For Hot-wire type - the airflow meter voltage value is displayed.)

(For Karman Vortex type - the airflow meter frequency value is displayed.)

(For Pressure sensor type - the pressure sensor voltage value is displayed.)

When the F-CON V Pro is used with the F-CON Navigator, the input signal converts to the intake air volume (l/min) and displays on the screen.

Knock : Knocking (0-100)

This value can be displayed only if the F-CON SZ or F-CON V Pro connects with "A/F Knock Amp."

The value range is from 0 to 100. "0" at no knocking signal, and "100" at the highest level of the signal.

The data in F-CON SZ or F-CON V Pro must be edited, but it cannot be changed with the F-CON Navigator.

Please contact an HKS distributor.

Speed : Vehicle speed (Km/h). * The unit measurement can be changed (see Sec. 5.6.5).

* The speed value for some vehicles, such as the JZS161 Aristo, cannot be displayed.

Inj.Out : The injector output opening rate (%)

3.2.2 Big Display Setup


Select one of the following 6 items for 'BIG'

• Boost • Airflow • A/F • Knock • Inj.Out • Ign.Out

Press arrow buttons () to select one, then press the SET button.

An asterisk (*) appears on both sides of the item selected.

Press the MODE button to return to the main menu.



BoostThe engine intake air pressure (×100kpa).

* The unit measurement can be changed (see Sec. 5.6.5).

This value can be displayed when the pressure sensor is installed.

The pressure sensor is sold separately.

The data in F-CON S, F-CON SZ or F-CON V Pro must be edited, but it cannot be changed with F-CON Navigator only.

Please contact an HKS distributor.

The absolute pressure value (0 at the vacuum state.) shows as the pressure value.

Please refer to the unit conversion table at the end of this manual.

AirFlow : Input airflow value (mV/Hz).

This input value can be displayed only if the F-CON Navigator is used with the F-CON S or F-CON SZ.

(For Hot-wire type - the airflow meter voltage value is displayed.)

(For Karman Vortex type - the airflow meter frequency value is displayed.)

(For Pressure sensor type - the pressure sensor voltage value is displayed.)

When the F-CON V Pro is used with the F-CON Navigator, the input signal converts to the intake air volume (l/min) and displays on the screen.

A/F : Air/fuel ratio.

This value can be displayed only when the "A/F Knock Amp" is used with the F-CON SZ or F-CON V Pro.

The data in F-CON SZ or F-CON V Pro must be edited, but it cannot be changed with the F-CON Navigator only. Please contact an HKS distributor.

Knock : Knocking (0-100)

This value can be displayed only if the F-CON SZ or F-CON V Pro connects with "A/F Knock Amp."

The value range is from 0 to 100. "0" at no knocking signal, and "100" at the highest level of the signal.

The data in F-CON SZ or F-CON V Pro must be edited, but it cannot be changed with the F-CON Navigator only. Please contact an HKS distributor.

Inj.Out : Injector output opening rate (%).

Ign.Out : Ignition timing output (BTDC). *BTDC is the angle before top dead center.

This value can be displayed only if the F-CON V Pro is used.

3.2.3.Small-L Display Setup


Select one of the following 6 items for 'Small-L'

• W. Temp • A. Temp • Volt. • Knock • Inj.R • Ign.R

Press arrow buttons () to select one, then press the SET button.

An asterisk (*) appears on both sides of the item selected.

Press the MODE button to return to the main menu.



- W.Temp. : Water temperature ().
The unit measurement can be changed. (see Sec. 5.6.5).
- A.Temp. : Intake air temperature (). * The unit measurement can be changed.
(See Sec. 5.6.5) If the vehicle does not have a temp sensor, the temperature cannot be displayed.
- Volt. : Battery voltage (V).
- Speed : Vehicle speed (Km/h).
You can change the unit. (See Sec. 5.6.5)
The speed value for some vehicles, such as the JZS161 Aristo, cannot be displayed.
- Inj.R. : Value of fuel correction(%) controlled by F-CON S or F-CON SZ.
Cannot be displayed with the F-CON V Pro.
- Ign.R. : Value of ignition correction (°)controlled by F-CON S or F-CON SZ.
Cannot be displayed with the F-CON V Pro.

3.2.4.Small-R Display Setup


Select one of the following 6 items for 'Small-R'

· W. Temp · A. Temp · Volt. · Knock · Inj.R · Ign.R

Press arrow buttons () to select one, then press the SET button.

An asterisk (*) appears on both sides of the item selected.

Press the MODE button to return to the main menu.



- W.Temp. : Water temperature ().
The unit measurement can be changed. (see Sec. 5.6.5).
- A.Temp. : Intake air temperature ().
The unit measurement can be changed. (See Sec. 5.6.5)
If the vehicle does not have a temp sensor, the temperature cannot be displayed.
- Volt. : Battery voltage (V).
- Speed : Vehicle speed (Km/h).
You can change the unit. (See Sec. 5.6.5)
The speed value for some vehicles, such as the JZS161 Aristo, cannot be displayed.
- Inj.R. : Value of fuel correction(%) controlled by F-CON S or F-CON SZ.
Cannot be displayed with the F-CON V Pro.
- Ign.R. : Value of ignition correction (°)controlled by F-CON S or F-CON SZ.
Cannot be displayed with the F-CON V Pro.

4. EDIT

Edit mode changes and checks the arrangement data inside F-CON.

This mode can be used only by F-CON S and F-CON SZ.

4.1. Edit Menu

Edit Menu consists of the following 4 items

Injector Data Edit Menu

Ignition Data Edit Menu

AIC Menu

Other Data Edit Menu

Press arrow buttons () to select one, then press SET button.

* The injector data edit & the ignition edit menu have the following 18 correction maps



- Injection A1-A4 • Injection B1-B4 • Injection Scramble • Ignition A1-A4
- Ignition B1-B4 • Ignition Scramble

Press the MODE button to move to the upward menu.

F-CON NAVIGATOR cannot change data of certain correction maps that are set by F-CONS and F-CON SZ. These unchangeable maps will not be displayed on the edit menu.

The activated correction map, which is chosen from the correction A1-A4 and B1-B4 by a dip switch, will be indicated with an asterisk.

In regards to fuel and timing correction in A1-A4 and B1-B4, the map title selected by the dip switch will be indicated with an asterisk.



4.2. Injection Data Edit (Inj.) / Ignition Data Edit (Ign.) / AIC (AIC)

The map consists of 24 columns and 16 rows.

The horizontal axis is for the engine rpm, and the vertical axis is for the engine load.

For the correction A1 to A4 is for the F-CON S & F-CON SZ, the default setting of the vertical axis is set to the airflow voltage.

The correction B1 to B4, the scramble correction, and AIC menu cannot be used.

*If you would like to change these default setting, please contact the power writer shop.

advice

- The DIP switch position of the F-CON S & F-CON SZ shows which correction map should be selected.

The correction map selected or displayed should be the same one activating on F-CON S & F-CON SZ Please refer to the manual of F-CON S & F-CON SZ about the DIP switch position and the correction maps.

- Injection Correction (A / B / Scramble)

This menu is to correct the value of the injector duty cycle. The unit is percentage 「%」.

- Ignition Correction (A / B / Scramble)

「°」 is the crank angle before top dead center (BTDC). Set "+" to advance the timing, and "-" to retard.

- AIC

This menu is to output by the additional injectors opening valve rate. The unit is 「%」.

4.2.1. Display

The name of the map is displayed at the bottom right of the display.

Only a small portion of the map, which is 4 x 4 cells, can be displayed at a time. See the scroll bar at the right or bottom of the map to see which part of the map is displayed.

The horizontal axis is for the engine rpm. The value increases as it moves to the right.

The vertical axis is for the engine load or the airflow meter voltage. The load/airflow increases as it moves downward.

The value from the sensor connected is displayed at the right of the display.

「NE」 Engine rpm

「FL」 Airflow voltage

「PR」 Intake air pressure

「TH」 Throttle position

「AF」 Air fuel ratio

「MP」 The value of the map selected or displayed.

The items selected for axis of the map are highlighted.

The value of the engine rpm and the engine load pointed by a cursor on the map are displayed at the bottom of the map.

「N」 Engine rpm

「L」 Engine load

If the vertical axis is for the airflow, the airflow meter voltage value is displayed.

If the vertical axis is for the boost, the boost value is displayed.

If the vertical axis is for the throttle, the throttle position is displayed.

When actual engine rpm and engine load are matched with the values on the map, F-CON Navigator places an underline on the map.

You can track down the data for setting with the position of the underline.

The bars are displayed until the map correction is finished.

4.2.2..Operation

Press arrows buttons () to select a part of the map you want to see or edit the data.

Press arrows buttons to scroll outside of the displayed map.

Press the SET button to start editing the data.

Press the MODE button to move to the upper menu.

Editing the Data


The actual value and edited value are displayed at the bottom right of the display.

Press the up arrow () to increase the data by 1.

Press the down arrow () to decrease the data by 1.

Press the SET button to make the edited data effective.

Press the MODE button to cancel editing.



4.3.Other Data Edit Menu (Etc.) - EIDS / FCD Map Setting (EIDS/FCD)

The size of the map is 24 cells wide and 1 cell high.

EIDS Function

The Electronic Idle Stabilizer (EIDS) function is to buffer the dramatic airflow meter signal fluctuations, prevents the engine stalling or stumbling effect associated with the sudden imbalances in the air/fuel ratio of airflow meter-equipped vehicles that utilize discharge blow-off valves that vent to the atmosphere.

FCD Function

The Fuel Cut Defencer (FCD) function is to override the high boost fuel cut function of factory turbocharged vehicles. The FCD function will widen the area of high boost which allows the vehicle to attain a much higher boost setting. However, the ECU tends to process the airflow volume less than the actual volume, so less fuel output is read, and the ignition timing is advanced accordingly.

advice

Because the ECU processes the airflow volume less than the actual volume; therefore, fuel output will decrease and ignition timing will advance.
The F-CON S and F-CON SZ are set to adjust these conditions.

4.3.1. E I D S

When the conditions of EIDS parameters are met, the F-CON NAVIGATOR sets the airflow output value to the engine RPM set by the EIDS map. (See Sec.4.4 for EIDS Parameter)
The data unit is " $\times 100\text{mV}$. "

If "100" is entered, the output value is 1,000 mV.

4.3.2. F C D

This menu is to enter the airflow voltage / frequency output maximum value.
The data unit is $\times 10\text{mV}$.

If "400" is entered, the maximum value is 4,000 mV.


4.3.3. Display

Please refer to Sec. 4.2.1.

The horizontal axis is for the engine rpm. The value increases as the graph moves to the right.

4.3.4.Operation

Please refer to Sec. 4.2.2.




4.4. EIDS Parameter Setting

- EIDS ON/OFF : Select "ON" to use the EIDS function.
- TIME : Set the length of the operating time of the EIDS function. This activates when the throttle becomes OFF.
- OnThro. : This is to see if the throttle valve is completely closed (OFF) or not (ON).
- Thro.0% : Normally, do not change the data here. This is to see the voltage when the throttle valve is completely off. When you select this item, the value of the throttle voltage is read and renewed automatically. Do not press the gas pedal when setting this item.

5. SYSTEM

5.1. System Setup Menu

This menu is for the operation setting or other miscellaneous setting of the F-CON Navigator. Press arrows button () to select one, and press the SET button. Press MODE button to move to the top menu.



5.2. Warning Menu


F-CON Navigator gives the warning when the in/output signal value is over the setting value of the boost, airflow voltage, knocking, and/or injector output by the buzzer and the message on the monitor. The warning menu is to activate this warning function.

5.2.1. Warning Menu

The monitor shows the value of the boost, knocking, airflow, and injector output presently entered.

Press arrows buttons () to select one, and press the SET button.

Press the MODE button to return to the system setup menu



5.2.2.Warning Setting

The item selected from the warning menu is displayed on the monitor.

Press the up arrow button () to increase the value by 1.

Press the down arrow button () to decrease the value by 1.

Press the right arrow button () to increase the value by 10.

Press the left arrow button () to decrease the value by 10.

Press the SET button when the value reaches to the suitable number, and return to the system setup menu.


Press the MODE button to cancel, and return to the system setup menu.

Setting Range : Boost Range: 0 ~ 4 0 0 K P a、 0 ~ 4 . 0 0 B a r、 6 0 0 0 P S I

Airflow Range: 0 ~ 5 0 0 0 m V / H z

Knocking Range: 0 ~ 1 0 0

Fuel Output Range: 0 ~ 1 0 0 %



5.3.Diagnosis Edit Menu (Diag.)

The diagnosis edit menu is to check if any error occurred in F-CON S, F-CON SZ, F-CON V Pro, and to delete the warning flag.


Error sometimes caused by wrong wiring of sensors or harnesses of F-CON S, F-CON SZ, and F-CON V Pro or the use of damaged sensors or harnesses.

The F-CON Navigator tells which sensor or harness is causing the error on the monitor, and it comes off when the error is corrected.

Disconnect the minus terminal from the battery when checking the wiring and rewiring the sensors.

Press the SET button to reset the warning flag.

Press the MODE button to return to the system setup menu.



5.4.Boot Mode Menu

The boot mode menu is to select the mode to show the top menu after the ignition is on.


Select one of the following modes

· Title1 · Title2 · Monitor · Top Menu

Press arrows buttons () to select , and press the SET button.

The asterisk (*) appears on the item selected.

Press the MODE button to return to the system setup menu.



Title 1

After the HKS logo appears, it stays until pressing any button.

Then, the top menu appears after pressing any button.

Title 2

After the HKS logo appears, the logo "F-CON Navigator" appears and stays until pressing any button.

Then, the top menu appears after pressing any button.

Monitor

After the HKS logo appears, the logo "F-CON Navigator" appears.

Then, it moves to the monitor menu.

TopMenu

After the HKS logo appears, the logo "F-CON Navigator" appears.

Then, it moves to the top menu.


5.5.Backup Menu

The backup menu is to save and load the data from F-CON SZ. This menu cannot use for F-CONS or F-CON V Pro.

When the setting data is saved before editing them, you can go back to the initial setting data.

Press the left and right arrows buttons () to select "SAVE," and press the SET button.

Press the MODE button to return to the system setup menu if a backup is not necessary.




S A V E

To save the data from F-CON SZ.


L O A D

To load the backup data.

After pressing the SET button, press the left/right arrow button () to select "Yes" for a backup.



When the backup is completed, the word "Complete" will appear as below. Press any button to return to the system setup menu.



5.6.Adjust Menu (Adjust)

5.6.1.Adjust

The adjust menu consists of the following 4 items:

LED Adjustment

LCD Adjustment


Buzzer Adjustment

Unit Selection

The adjust menu is to adjust the F-CON Navigator's miscellaneous functions.

Press arrows buttons () to select, and press the SET button.

Press the MODE button to return the system setup menu.



5.6.2. LED

The LED menu is to adjust brightness of LED backlight.

You can select the brightness by numbers. The level of brightness goes up when the number increases.

Press the up arrow button () to increase the data by 1.

Press the down arrow button () to decrease the data by 1.

Press the right arrow button () to increase the data by 10.


Press the left arrow button () to decrease the data by 10.

Press the SET button when the number is selected, and return to the adjust menu.

Press the MODE button to cancel, and return to the adjust menu.

Setting Romge : LED Range 0~100(0 : Darkest ↔ 100 : Brightest)
 LCD Range 0~100(0 : Lightest / white ↔ 100 : Darkest / Black)
 Buzzer Range ONorOFF
 Unit Range 0~4(TO select a unit combination for boost,speed and temperature.)


Range	Boost Unit	Speed Unit	Temperature
0	Pascal (x100kPa)	kilometer (km/h)	Celsius (°C)
1	Pascal (x100kPa)	Mile (MPH)	Celsius (°C)
2	Bar (bar)	kilometer (km/h)	Celsius (°C)
3	Bar (bar)	Mile (MPH)	Celsius (°C)
4	Pound (psi)	Mile (MPH)	Fahrenheit (°F)



5.7.Other (About)

This about menu is to see which type of F-CON is connected and the version of F-CON Navigator is used.

Press any button to return to the system setup menu.



Maintenance

Check the vehicle condition daily.

Handle the product with clean hands.

The color of the product case might discolor by any dirt such as oil.

Clean the product with dry, soft cloth. Don't use alcohol, thinner, benzene, glass cleaner, oil, and other solvent.

Specification of the product

Operating Voltage.....DC10 ~ 16V

Operating Temperature - 10 ~ 70

Maximum consumed electric power.....3W

< Unit Conversion Table >

Output	1PS = 0.735kW	/	1kW = 1.36PS
Torque	1kgf · m = 9.81N · m	/	1N · m = 0.102kgf · m
Pressure	1kgf/cm ² = 98.1kPa	/	1kPa = 0.0102kgf/cm ²
Atmospheric Pressure	1kPa = 7.50mmHg	/	1mmHg = 0.1333kPa

Record of Revision

Ver.	Date	Ver.
3-1.00	2003 / 8	1st edition



Pursuing the Ultimate in Engine Performance and Efficiency.
Produced by HKS Company Limited.